



ACN Iris WG4K Handset Replacement

Replace the malfunctioning handset from your ACN Iris WG4K.

Written By: Itze Kenney



INTRODUCTION

The handset is typically used for regular phone conversations that exclude video. It creates a private form of communication as opposed to using the speakers and video phone. If the handset is damaged, or malfunctioning this guide will show you how simple it is to replace it.

Step 1 — Handset



- Press upwards with your index finger on the 4P4C connector as shown in the image.
- Pull the connector gently out of its socket.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 09:16:11 PM.